

# TX3-T10RH Rain/Sun Cover Installation Instructions

This document provides instructions for wall-mount installation only. For pedestal-mount installation procedures, refer to document LT-6792.

TX3-T10RH supports the following model:

- TX3-T10 Series

Included in Kit:

- TX3-T10RH rain/sun cover
- 2 flat head #6 screws for hanging TX3-T10RH on the wall
- 1 screwdriver for securing the 4 TX3-T10 security screws

You need:

- Four fasteners appropriate for the wall, for securing TX3-T10RH and TX3-T10BB to the wall

## Dimensions





Figure 1. TX3-T10RH dimensions

## Step 1: Hang TX3-T10RH on the Wall

1. Cut an opening in the wall for a 4x4" electrical box. The electrical box must have a depth of at least 2.27".
2. Align TX3-T10RH directly against the wall surface and use the dimensions on page 1 to determine the position of the electrical cutout.
3. Insert the included two flat head #6 screws and tighten them to hold TX3-T10RH to the wall (see Figure 2).

**Note:** **This step makes it easy to hold TX3-T10RH in place against the wall so that you can install TX3-T10BB.**



**Figure 2. Hang TX3-T10RH on the wall**

Mircom

<http://www.mircom.com>

CANADA - Main Office

25 Interchange Way

Vaughan, ON L4K 5W3

Tel: (888) 660-4655

(905) 660-4655

U.S.A

4575 Witmer Industrial Estates

Niagara Falls, NY 14305

Tel: (888) 660-4655

Subject to change without prior notice.

LT-6791 Rev 1 See <https://mircom.com/> for the latest information

Page 2 of 3

## Step 2: Secure TX3-T10BB and TX3-T10RH to the Wall

1. Route the wiring through the TX3-T10BB knockout and into the electrical box.
2. Install the ferrites on the network cable and the power cable as shown in LT-6766 (TX3-T10 Installation Manual). Place the ferrites in the electrical box.
3. Follow the instructions in instruction manual LT-6766 (TX3-T10 Installation Manual) to attach the electrical box to the TX3-T10BB backbox.
4. Insert four fasteners appropriate to the wall, along with the four washers included with TX3-T10BB, and tighten them to secure the TX3-T10BB and TX3-T10RH to the wall (see Figure 3).
5. Connect the ground wires as described in manual LT-6766 (TX3-T10 Installation Manual).
6. Install the TX3-T10 onto the secured TX3-T10BB as described in instruction manual LT-6766 (TX3-T10 Installation Manual).

**Note:** Use the included small screwdriver to secure the 4 screws that secure TX3-T10 in TX3-T10BB. This screwdriver is small enough to fit under the rain/sun cover.




Figure 3. Mount the backbox and rain/sun cover to the wall