

## RB-MD-1095 Installation Instructions

1. Turn off the current controller board.
2. Disconnect the power harness from the power connector on the current controller board.
3. Disconnect all connectors, ribbon cables, and harnesses from the current controller board.
4. Unscrew the six screws that hold the controller board in place.
5. Remove the current board and replace it with the new MD-1095 controller board.
6. Secure the new board with the six screws you removed in step 4.
7. Connect the connectors, ribbon cables, and harnesses that you removed in step 3 to the new board.
8. Connect the power harness to the power connector on the new board.
9. Turn on the new board.

**Figure 1: RB-MD-1095 TX3-NSL-8M Board Replacement**

