

ENTER Apartment Number
(up to 8 digits)

Enter Apt#
[]

ENTER Dial Code
(up to 4 digits)

Enter Dial Code

ENTER Main Door Security Code

Leave as 0

Main Door sec. code

ENTER Auxiliary Door Security Code

Leave as 0

Aux Door sec. code

ENTER Resident Name
(maximum 15 characters)

Enter Resident Name
[]

ENTER Line in Use

Line in Use
 Line 1
 Line 2
 Line 3
 Line 4
 Line 5

ENTER Phone Number
ADC SYSTEM ONLY
Maximum of 18 digits
Use "" to pause for 1 second
Use "," to pause for 3 seconds

For "" PRESS

For "," PRESS

Enter Phone Number

ENTER Relay Code
NSL SYSTEM ONLY

Enter Relay Code
[]

ENTER Keyless Code
Up to 6 Digits
See User Guide for more info

Enter Keyless Code
[]

ENTER Keyless Correlation

Keyless Code Corr
 Main door relay
 Aux door relay

ENTER Elevator Restriction Address

Enter Elev Rest Addr
[]

ENTER Elevator Rest Relay

Enter Elev Rest Code
[]

HIDE Display

Hide Display
 Display

ENTER Ring Pattern
NSL SYSTEM ONLY

Ring Pattern
 Ring Pattern 1
 Ring Pattern 2
 Ring Pattern 3
 Ring Pattern 4
 Ring Pattern 5

IF CREATING A NEW RECORD
YOU WILL SEE

New Resident Record Added

4 DELETE A RECORD

FROM THE DATABASE MENU

Scroll DOWN to **3 Delete Record**

PRESS

YOU WILL NOW SEE THE LIST OF RESIDENTS

1212 Smith
1213 Franklin
1214 Darwin
1215 Newton

Scroll UP or DOWN to the desired record

PRESS

THE RECORD IS NOW DELETED

Next Generation
Communications & Security



TX3 Series

VOICE ENTRY

Quick Reference Guide: Voice Entry Systems

NAVIGATING MENUS

1 2 ABC 3 DEF ↑ Scroll UP

4 GHI 5 JKL 6 MNO ↓ Scroll DOWN

7 PQRS 8 TUV 9 WXYZ ☎ ENTER

* 0 # ⓘ CANCEL

Scroll LEFT Scroll RIGHT

ENTERING INFORMATION

SYMBOL KEY	
PRESS	
once	,
twice	-
3 times	(
4 times)
5 times	/
6 times	&
9 times	*
10 times	1

* KEY	
PRESS	
once	moves cursor left

0 KEY	
PRESS	
once	deletes character
twice	space

# KEY	
PRESS	
once	moves cursor right

1 ENTER CONFIGURATION MODE

PRESS

WHEN YOU SEE **1 Configuration** PRESS

ENTER PASSCODE (provided by installer)

then PRESS

YOU ARE NOW IN THE CONFIGURATION MENU

Main Menu

- 1 System Option
- 2 Database
- 3 Schedules
- 4 Holidays
- 5 Factory Dflt
- 6 Input/Output
- 7 Correlation
- 8 Change Passcode
- 9 Test LCD

2 MANAGE RECORDS

ENTER CONFIGURATION MODE

Scroll DOWN to **2 Database**

PRESS

YOU WILL NOW SEE

Database

- 1 Add Record
- 2 Edit Record
- 3 Delete Record
- 4 Sort by name
- 5 Sort by d-code
- 6 Auto program
- 7 Delete all rec

Scroll DOWN to your desired option

PRESS

YOU CAN NOW MANAGE RECORDS

3 ADD/ EDIT A RECORD

FROM THE DATABASE MENU

Scroll to ADD RECORD or EDIT RECORD

PRESS

If you chose EDIT RECORD scroll to the desired record

PRESS

Scroll to the desired information you wish to edit

PRESS