



UIMA4

Description

The UIMA4 is an interface for configuring FleX-Net™, FA-300, FX-350, FX-2000, FX-3500, FX-3318, QX-5000, UDACT-300, MR-2300, MR-2350 and MMX panels.

The UIMA4's ribbon cable can be disconnected and replaced

Interface

The UIMA4 interface has 3 connectors.


- 9 pin male serial connector for connecting the UIMA4 to the 9 pin male to female serial cable and then to the RS-232 serial port on some products
- USB B female connector for connecting the UIMA4 to the USB A to B male cable and then to the computer
- 10 pin female connector for connecting the UIMA4 to the configuration port or debug interface on some products



9-Pin Male
Serial
Connector



USB B
Female
Connector




10-Pin
Female
Connector

Features

- For configuring the following panels:
 - FleX-Net™
 - FA-300
 - FX-350
 - FX-2000
 - FX-3500
 - FX-3318
 - QX-5000
 - UDACT-300
 - MR-2300
 - MR-2350
 - MMX
- For use with the FleX-Net™ MP Upgrade Wizard
- Includes one replacement 10 pin cable

Replacement Ribbon Cable



Ordering Information

Model	Description
UIMA4	Interface for Configuring MGC Fire Panels
RPL-WC-25022	Replacement Ribbon Cable for UIMA4 (Pack of 3)
MGC-CONFIG-KIT4	Fire Panel Configuration KIT1 with UIMA4

Canada

25 Interchange Way Vaughan, ON L4K 5W3
Telephone: (905) 660-4655 | Fax: (905) 660-4113

U.S.A.

4575 Witmer Industrial Estates Niagara Falls, NY 14305
Toll Free: (888) 660-4655 | Fax Toll Free: (888) 660-4113

www.mircom.com



THIS INFORMATION IS FOR MARKETING PURPOSES ONLY AND NOT INTENDED TO DESCRIBE THE PRODUCTS TECHNICALLY.

For complete and accurate technical information relating to performance, installation, testing and certification, refer to technical literature. This document contains intellectual property of Mircom. The information is subject to change by Mircom without notice. Mircom does not represent or warrant correctness or completeness.