


Parts required:


- 2 x nuts for securing postal lock
- 2 x screws for postal lock switch
- 2 x washers for postal lock switch
- 1 x postal lock switch with cable
- 1 x switch holder
- 1 x postal lock window
- 1 x postal lock plate

1. **Disconnect the Power**

2. **Remove the Card Reader Window**




3. Use the 4 Nuts to Secure the Postal Lock Window, Plate, and Switch Holder



LT-6610 Rev 1 June 2017

4. Attach the Switch Washers (x2) Postal lock switch Screws (x2)

5. Attach the Postal Lock



6. Wire the Switch

Wire the postal lock switch to Input 1 with the included cable. Note: Do not wire the switch until after the postal lock is installed.

