

QPS-6650 Wiring

Refer to Figure 2 wiring information. AC voltage in is wired to the bottom left terminals, all other wiring is at the top terminals. For further wiring instruction see LT-6683 manual.

Figure 2 QPS-6650 Power Supply Wiring

