


QIF-1000

Interface Module



The QIF-1000 Interface board enables All Call paging for multiple building applications using the QX-5000. Set **ALL** DIP switches of SW1 to the ON position for Master operation or set **ALL** DIP switches of SW1 OFF for slave operation of this interface board.

Figure 1: QIF-1000 Interface Board.





Figure 2: Mounting the QIF-1000 Interface Module



The QIF-1000 Interface module comes already mounted onto a CH-559 Plate. The CH-559 mounts onto the QBC-5000B battery charger cover located above the amplifiers in the audio cabinet of the QX-5000 Audio system. The QBC-5000B must be removed and the QIF-1000 ,and its plate is mounted onto the QBC-5000B with four #4 screws behind the QBC-5000B cover. The whole assembly is then mounted back into the audio cabinet over the battery charger.

Canada
25 Interchange Way
Vaughan, ON L4K 5W3
Tel: 905-660-4655 Fax: 905-660-4113

U.S.A.
60 Industrial Parkway
Cheektowaga, NY 14227
Tel: 1-888-660-4655 Fax: 1-888-660-4113

© Mircom 2005
Printed in Canada
Subject to change without prior notice
www.mircom.com