


NOTES:

1. TO WIRE QAA-4CLAS, REMOVE TERMINAL FROM QAA-5230S-70/25 or QAA-5230S-525-70/25 AMPLIFIER, CONNECT TO QAA-4CLAS AND SCREW DOWN. WIRE THE FOUR CLASS A CIRCUITS TO THE 16 TERMINALS AS SHOWN IN DIAGRAM AT RIGHT.
2. ALL CIRCUITS ARE POWER LIMITED.
3. 5 WATTS MAX. PER ZONE.



**QAA-4CLAS
TERMINAL BLOCK**



QAA-4CLAS Class A Converter For QAA-5230S-70 /25 and QAA-5230S- 525-70/25 Amplifiers