

FDS-008 Fan Damper Control Module





Installation and Wiring Manual

LT-601 Rev. 4 September 2012

1.0 Introduction	1
2.0 Jumpers and Terminals Descriptions	2
2.1 Jumpers	2
2.3 Relay Contacts Terminals	2
2.4 Circuit Terminals	2
2.5 AC Power Terminals	2
2.6 DC Power Terminals	2
2.7 Chassis Ground	3
2.8 Wiring Instruction	3
Warranty & Warning Information	5

1.0 Introduction

MGC's universal Fan Damper Control module, Model FDS-008, is designed to handle up to 8 fan control circuits. Each circuit comes with Form C relay contacts and indicators for Fan Status: "ON" (green) or "OFF" (red). In addition, each circuit is provided with a three position slide switch to independently set the fan to either "OFF", "AUTO", or "ON". In "AUTO" mode setting, each circuit can be wired in parallel so that all the fans connected to it activate at the same time whenever the Fire Alarm Unit is active or in "alarm". Also, any of the circuits can be configured as "Normally On" (for building air circulation which automatically will shut off whenever an "alarm" condition occurs to avoid spreading the smoke) or "Normally Off" (which activates only when an "alarm" condition occurs to pressurize the stairway areas) as needed. Furthermore, an input terminal is provided per circuit to monitor the status of the fan.

The FDS-008 module can be powered with a 24VDC, 300 mA external DC power source or by using MGC's standard Model PS-24 power transformer. For more details, please call our Technical Support department.



2.0 Jumpers and Terminals Descriptions

2.1 Jumpers

JW1 to JW8 These jumpers are used to monitor the fan OFF status while the switch is set to "AUTO".

Factory default is on (jumper's sockets are installed). Jumper functions: jumper(s) on (pins are shorted) -fan status OFF LED is "on" at AUTO mode. jumper(s) out (pins are open) -fan status OFF LED is "off" at AUTO mode.

JW9 to JW24 These jumpers are used to provide a positive voltage (+24VDC) to the fan status indicators if the fan status relay contacts are not available on the Fan Unit. Fan status relay contacts are normally provided on the Fan Unit that energizes whenever the fan is "turned on" for remote confirmation. Factory default for these jumpers is on (jumper's sockets are installed). Remove these jumpers selectively to monitor the fan status and wire the "ON(+)" and "OFF(+)

terminals to fan status relay contacts on the fan unit. Please refer to the Wiring Instruction section shown on the next page.

Jumpers JW9,11,13,15,17,19,21,and 23 are used for "ON(+)" terminals.

Jumpers JW10,12,14,16,18,20,22, and 24 are used for "OFF(+) terminals.

2.3 Relay Contacts Terminals

Relay # 1 to 8 These terminals are used to control the fans. Refer to Wiring Instruction section for details. Form C, [NO (normally open), C (common), and NC (normally closed)] 2 Amp. Max. @ 30VDC (resistive load), 0.6 Amp. Max. @ 125VAC, 0.6 Amp. Max @ 110VDC

2.4 Circuit Terminals

Circuit # 1 to 8	Three terminals are provided per circuit and are described below.
AUTO(-) Unit.	This terminal is used to connect to "alarm" relay contacts provided by the Fire Alarm Control
	Note: Connect the "C (common)" contact of the alarm relay to COM(-) terminal.
ON(+)	This terminal is used to monitor the "ON" status of the fan. Remove JW9 -JW23 (odd jumpers) selectively as mentioned above.
	Connect this terminal to fan status relay contacts (NO or NC) provided by the Fan Unit.
OFF(+)	This terminal is used to monitor the "OFF" status of the fan. Remove JW10-JW24 (even jumpers) selectively as mentioned above. Connect this terminal to fan status relay contacts (NO or NC) provided by the Fan Unit.
	Note: Please refer to the Wiring Instruction section for details.

2.5 AC Power Terminals

T1 & T2AC power input terminals for 24VAC power transformer.Use MGC's PS-24 (24VAC, 40VA, Class 2 type) standard power transformer.Note: PS-24 power transformer can power two FDS-008 modules.

2.6 DC Power Terminals

COM(+) Power limited +24VDC output voltage, 5 mV ripple, 300 mA Max. (Using PS-24 transformer) COM(-) Common ground or system electrical ground.

Note: These terminals can be used to connect an external non-resettable 24VDC power source to power this module. Make sure that the source can provide at least 300 mA per FDS-008 module.

Caution:Do not use these terminals as a power source for other applications not mentioned in this document.

2.7 Chassis Ground

Connect one of the PCB mounting hole (Chassis Ground) to Earth Ground (cold water pipe).

2.8 Wiring Instruction

Wire the unit as shown below. Use proper wire gauge.



Typical FDS-008 Internal Circuitry:

NOTES:

1. Form C Relay Dry Contacts. Do not exceed maximum ratings specified below.

2.0 Amperes Max. at 30 VDC (Resistive Load),0.6 Amperes Max. at 125 VAC or 110 VDC.

- 2. Remove Jumpers selectively. See Jumper description for details.
- 3. All wiring must be 18 AWG Minimum, 2000 feet (610 m) Maximum run.
- 4. For internal circuitry, refer to previous diagram.
- 5. Use PS-24 Power Transformer if 24 VDC Power Source is not available; this can power up to o two FDS-008 Modules. If using an Auxiliary Power Supply, or 4-Wire Power Supply from a Fire Alarm Control Panel, that supply must not be used for any other purpose.
- 6. COM (-) and COM (+) Terminals must not be used for applications other than those mentioned in this document.
- 7. There are 8 Fan Circuits available per FDS-008 Module.

Warranty & Warning Information

Warning Please Read Carefully

Note to End Users: This equipment is subject to terms and conditions of sale as follows:

Note to Installers

This warning contains vital information. As the only individual in contact with system users, it is your responsibility to bring each item in this warning to the attention of the users of this system. Failure to properly inform system end-users of the circumstances in which the system might fail may result in over-reliance upon the system. As a result, it is imperative that you properly inform each customer for whom you install the system of the possible forms of failure.

System Failures

This system has been carefully designed to be as effective as possible. There are circumstances, such as fire or other types of emergencies where it may not provide protection. Alarm systems of any type may be compromised deliberately or may fail to operate as expected for a variety of reasons. Some reasons for system failure include:

Inadequate Installation

A Fire Alarm system must be installed in accordance with all the applicable codes and standards in order to provide adequate protection. An inspection and approval of the initial installation, or, after any changes to the system, must be conducted by the Local Authority Having Jurisdiction. Such inspections ensure installation has been carried out properly.

•Power Failure

Control units, smoke detectors and many other connected devices require an adequate power supply for proper operation. If the system or any device connected to the system operates from batteries, it is possible for the batteries to fail. Even if the batteries have not failed, they must be fully charged, in good condition and installed correctly. If a device operates only by AC power, any interruption, however brief, will render that device inoperative while it does not have power. Power interruptions of any length are often accompanied by voltage fluctuations which may damage electronic equipment such as a fire alarm system. After a power interruption has occurred, immediately conduct a complete system test to ensure that the system operates as intended.

•Failure of Replaceable Batteries

Systems with wireless transmitters have been designed to provide several years of battery life under normal conditions. The expected battery life is a function of the device environment, usage and type. Ambient conditions such as high humidity, high or low temperatures, or large temperature fluctuations may reduce the expected battery life. While each transmitting device has a low battery monitor which identifies when the batteries need to be replaced, this monitor may fail to operate as expected. Regular testing and maintenance will keep the system in good operating condition.

Compromise of Radio Frequency (Wireless) Devices

Signals may not reach the receiver under all circumstances which could include metal objects placed on or near the radio path or deliberate jamming or other inadvertent radio signal interference.

System Users

A user may not be able to operate a panic or emergency switch possibly due to permanent or temporary physical disability, inability to reach the device in time, or unfamiliarity with the correct operation. It is important that all system users be trained in the correct operation of the alarm system and that they know how to respond when the system indicates an alarm.

Automatic Alarm Initiating Devices

Smoke detectors, heat detectors and other alarm initiating devices that are a part of this system may not properly detect a fire condition or signal the control panel to alert occupants of a fire condition for a number of reasons, such as: the smoke detectors or heat detector may have been improperly installed or positioned; smoke or heat may not be able to reach the alarm initiating device, such as when the fire is in a chimney, walls or roofs, or on the other side of closed doors; and, smoke and heat detectors may not detect smoke or heat from fires on another level of the residence or building.

Software

Most MGC products contain software. With respect to those products, MGC does not warranty that the operation of the software will be uninterrupted or error-free or that the software will meet any other standard of performance, or that the functions or performance of the software will meet the user's requirements. MGC shall not be liable for any delays, breakdowns, interruptions, loss, destruction, alteration or other problems in the use of a product arising our of, or caused by, the software.

Every fire is different in the amount and rate at which smoke and heat are generated. Smoke detectors cannot sense all types of fires equally well. Smoke detectors may not provide timely warning of fires caused by carelessness or safety hazards such as smoking in bed, violent explosions, escaping gas, improper storage of flammable materials, overloaded electrical circuits, children playing with matches or arson.

Even if the smoke detector or heat detector operates as intended, there may be circumstances when there is insufficient warning to allow all occupants to escape in time to avoid injury or death.

•Alarm Notification Appliances

Alarm Notification Appliances such as sirens, bells, horns, or strobes may not warn people or waken someone sleeping if there is an intervening wall or door. If notification appliances are located on a different level of the residence or premise, then it is less likely that the occupants will be alerted or awakened. Audible notification appliances may be interfered with by other noise sources such as stereos, radios, televisions, air conditioners or other appliances, or passing traffic. Audible notification appliances, however loud, may not be heard by a hearing-impaired person.

•Telephone Lines

If telephone lines are used to transmit alarms, they may be out of service or busy for certain periods of time. Also the telephone lines may be compromised by such things as criminal tampering, local construction, storms or earthquakes.

Insufficient Time

There may be circumstances when the system will operate as intended, yet the occupants will not be protected from the emergency due to their inability to respond to the warnings in a timely manner. If the system is monitored, the response may not occur in time enough to protect the occupants or their belongings.

•Component Failure

Although every effort has been made to make this system as reliable as possible, the system may fail to function as intended due to the failure of a component.

Inadequate Testing

Most problems that would prevent an alarm system from operating as intended can be discovered by regular testing and maintenance. The complete system should be tested as required by national standards and the Local Authority Having Jurisdiction and immediately after a fire, storm, earthquake, accident, or any kind of construction activity inside or outside the premises. The testing should include all sensing devices, keypads, consoles, alarm indicating devices and any other operational devices that are part of the system.

•Security and Insurance

Regardless of its capabilities, an alarm system is not a substitute for property or life insurance. An alarm system also is not a substitute for property owners, renters, or other occupants to act prudently to prevent or minimize the harmful effects of an emergency situation.

IMPORTANT NOTE: End-users of the system must take care to ensure that the system, batteries, telephone lines, etc. are tested and examined on a regular basis to ensure the minimization of system failure.

Limited Warranty

Mircom Technologies Ltd., MGC Systems Corp. and MGC System International Ltd. together with their subsidiaries and affiliates (collectively, MGC) warrants the original purchaser that for a period of three years from the date of shipment, proprietary manufactured product shall be free of defects in materials and workmanship, under normal use. During the warranty period, MGC shall, at its option, repair or replace any defective product upon return of the product to its factory, at no charge for labor and materials. Non-proprietary, third party or OEM product shall be warranted in accordance with the warranty period of the manufacturer. Any replacement and/or repaired parts are warranted for the remainder of the original warranty or ninety (90) days, whichever is longer. The original owner must promptly notify MGC in writing that there is defect in material or workmanship, such written notice to be received in all events prior to expiration of the warranty period.

International Warranty

The warranty for international customers is the same as for any customer within Canada and the United States, MGC shall not be responsible for any customs fees, taxes, or VAT that may be due.

Conditions to Void Warranty

This warranty applies only to defects in parts and workmanship relating to normal use. It does not cover:

•damage incurred in shipping or handling;

•damage caused by disaster such as fire, flood, wind, earthquake or lightning;

•damage due to causes beyond the control of MGC such as excessive voltage, mechanical shock or

•water damage;

•damage caused by unauthorized attachment, alterations, modifications or foreign objects;

•damage caused by peripherals (unless such peripherals were supplied by MGC);

•defects caused by failure to provide a suitable installation environment for the products;

•damage caused by use of the products for purposes other than those for which it was designed;

•damage from improper maintenance;

•damage arising out of any other abuse, mishandling or improper application of the products.

Warranty Procedure

To obtain service under this warranty, please return the item(s) in question to the point of purchase. All authorized distributors and dealers have a warranty program. Anyone returning goods to MGC must first obtain an authorization number. MGC will not accept any shipment whatsoever for which prior authorization has not been obtained. NOTE: Unless specific pre-authorization in writing is obtained from MGC management, no credits will be issued for custom fabricated products or parts or for complete fire alarm system. MGC will at its sole option, repair or replace parts under warranty. Advance replacements for such items must be purchased.

Note: MGC's liability for failure to repair the product under this warranty after a reasonable number of attempts will be limited to a replacement of the product, as the exclusive remedy for breach of warranty.

Disclaimer of Warranties

This warranty contains the entire warranty and shall be in lieu of any and all other warranties, whether expressed or implied (including all implied warranties of merchantability or fitness for a particular purpose) and of all other obligations or liabilities. MGC neither assumes nor authorizes any other person purporting to act on its behalf to modify or to change this warranty, or to assume for it any other warranty or liability concerning this product.

This disclaimer of warranties and limited warranty are governed by the laws of the province of Ontario, Canada.

Out of Warranty Repairs

MGC will at its option repair or replace out-of-warranty products which are returned to its factory according to the following conditions. Anyone returning goods to MGC must first obtain an authorization number. MGC will not accept any shipment whatsoever for which prior authorization has not been obtained.

Products which MGC determines to be repairable will be repaired and returned. A set fee which MGC has predetermined and which may be revised from time to time, will be charged for each unit repaired.

Products which MGC determines not to be repairable will be replaced by the nearest equivalent product available at that time. The current market price of the replacement product will be charged for each replacement unit.

The foregoing information is accurate as of the date of publishing and is subject to change or revision without prior notice at the sole discretion of the Company

WARNING: MGC recommends that the entire system be completely tested on a regular basis. However, despite frequent testing, and due to, but not limited to, criminal tampering or electrical disruption, it is possible for this product to fail to perform as expected.

NOTE: Under no circumstances shall MGC be liable for any special, incidental, or consequential damages based upon breach of warranty, breach of contract, negligence, strict liability, or any other legal theory. Such damages include, but are not limited to, loss of profits, loss of the product or any associated equipment, cost of capital, cost of substitute or replacement equipment, facilities or services, down time, purchaser's time, the claims of third parties, including customers, and injury to property.

MGC MAKES NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO ITS GOODS DELIVERED, NOR IS THERE ANY OTHER WARRANTY, EXPRESSED OR IMPLIED, EXCEPT FOR THE WARRANTY CONTAINED HEREIN.

Notes



CANADA - Main Office 25 Interchange Way Vaughan, ON L4K 5W3 Tel: (888) 660-4655 (905) 660-4655 Fax: (905) 660-4113 U.S.A 4575 Witmer Industrial Estates Niagara Falls, NY 14305 Tel: (888) 660-4655 (905) 660-4655 Fax: (905) 660-4113 TECHNICAL SUPPORT North America Tel: (888) Mircom5 (888) 647-2665 International Tel: (905) 647-2665

© MGC 2012 Printed in Canada Subject to change without prior notice www.mircomgroup.com