




# BB-700WP Installation Instructions




1. Remove the adhesive backing paper from the GK-022 neoprene gasket.




2. Align the four screw holes on the back in the gasket with the matching holes on the back of the BB-700WP.




3. Press the adhesive side of the GK-022 firmly into place on the BB-700WP. The BB-700WP is now ready for mounting. When mounting the BB-700WP ensure the arrow on the inside of the backbox is pointing upwards.




4. Remove the adhesive backing paper from the GK-021 neoprene gasket.




5. Align with the four mounting holes and terminal block on the back of the manual station.




6. Press the adhesive side of the GK-021 firmly into place on the manual station.



7. Ensure that the arrow on the inside of the BB-700WP is pointing upwards and unlock the manual station.



8. Align the four mounting holes of the manual station and the BB-700WP.



9. Firmly press the manual station onto the BB-700WP and secure with the screws provided.