



### Features

- Provides 5 hardwired telephone circuits
- First circuit configurable for the master telephone handset.
- Removeable terminal blocks
- Mounts with the ANC-5000 on a plate in the QMB-5000N audio card cage or in the FXMNS main chassis

### Description

The TNC-5000 provides five hardwired telephone circuits for the local floor panel with the first circuit configurable for the master telephone handset. The TNC-5000 mounts with the ANC-5000 on a plate in the QMB-5000N audio card cage or in the FX-MNS main chassis.

### Power Consumption

<b>Normal Operation Voltage</b>	Amps
<b>Stand by</b>	195 mA
<b>Alarm</b>	215 mA

### Ordering Information

Model	Description
TNC-5000	Telephone Network Controller Module



#### Canada

25 Interchange Way Vaughan, ON L4K 5W3  
Telephone: (905) 660-4655 | Fax: (905) 660-4113

#### U.S.A.

4575 Witmer Industrial Estates Niagara Falls, NY 14305  
Toll Free: (888) 660-4655 | Fax Toll Free: (888) 660-4113

www.mircom.com



**THIS INFORMATION IS FOR MARKETING PURPOSES ONLY AND NOT INTENDED TO DESCRIBE THE PRODUCTS TECHNICALLY.**

For complete and accurate technical information relating to performance, installation, testing and certification, refer to technical literature. This document contains intellectual property of Mircom. The information is subject to change by Mircom without notice. Mircom does not represent or warrant correctness or completeness.

**CATALOG NUMBER 5339**

Rev. 1